


# TURFSTONE




TURFSTONE: Natural (Grass Fill)

LIVE LIFE IN COLOR!

**nicolock**<sup>®</sup>  
paving stones & retaining walls  
 **paver-shield**<sup>™</sup>




# TURFSTONE



## FEATURES

Rectangular shape • Lattice concrete grid • Flat surfaces  
40% open surface area



## COLOR SELECTION



natural


## SPECIFICATIONS

|          | width | length | thickness | s.f./per pc. | s.f./pallet | pcs./pallet | lbs./pallet |
|----------|-------|--------|-----------|--------------|-------------|-------------|-------------|
| <b>A</b> | 16"   | 24"    | 3-1/8"    | .38          | 93          | 35          | 2,100       |

## INSTALLATION GUIDELINES: SAND

After excavation, compact the subgrade and install a woven separation fabric. Spread and compact a base of clean, graded, dense aggregate (road base). Typical compacted base thickness is 4-6" for pedestrian applications. Pavers are set on a loosely screeded 1" bed of graded, clean concrete sand. Maintain a joint size of 1/16" - 3/16". When pavers are set, compact paving stones into sand with mechanical plate vibrator. Joint sand may be spread over paving stones during compaction. Installed pavers should be set 1/8" to 1/4" above final elevations to compensate for any potential settlement. Spread clean dry sand over surface and broom sweep to fill joints.

## CROSS-SECTION OF TYPICAL INSTALLATION



**NOTE:** All measurements are nominal. Variance in square footage or linear footage coverage can be up to 5% depending on joint width. The possible occurrence of efflorescence does not affect the structural integrity of the product. Efflorescence is a normal occurrence in concrete products and will dissipate with normal weathering. The use of concrete as a base or setting bed may increase the possibility of efflorescence.

**CAUTION:** Always use a plate compactor with a pad when installing any textured paving stone.